# Make-A-Berm<sup>™</sup> Installation Guide



#### Make-A-Berm Kit includes:

Barriers, Corners, Sealant, Glue and Vinyl Collar

## **Before Installation**

Clean the floor out of any debris. Any buildup of grease and oil must be removed. Failure to do so may result in premature failure of the Make-A-Berm barrier sealant.



# **Simple & Easy Installation**

- 1. Apply two continuous beads of sealant on the bottom of the Make-A-Berm, approximately 2,5 cm from the sides and ends for the entire length.
- 2. Place the Make-A-Berm and apply pressure to the entire length to seal to floor.
  - Note: To ensure proper sealing on uneven surfaces, it may be necessary to apply extra sealant and more direct pressure.
- 3. Adding Two Sections: Cut the vinyl collar to length and apply the Type A glue to both surfaces. Mold the collar over the two surfaces, pushing out any wrinkles for about 30 seconds.
  - Note: When attaching two sections together, be sure the Make-A-Berm sections are as straight as possible. Cut enough vinyl collar to cover the entire seam on both sides.
- **4.** Attaching Corners: Position corner, roll back material and apply Type A glue to both surfaces. Mold the material over the two surfaces, pushing out any wrinkles for about 30 seconds.



Apply a continuous bead of sealant along the entire length



Attach corners using Type A Glue



Assembled Make-A-Berm

### **Important Notes**

- To apply the Make-A-Berm over cracks and expansion joints, first fill these areas with sealant. Allow to cure before installing.
- If the Make-A-Berm barrier that has been stored coiled up, uncoil and allow it to sit uncoiled 2-4 hours before installing.
- To cut the Make-A-Berm barrier, use a utility knife along with a straight edge.
- Temperatures below 21°C may require the Make-A-Berm to relax before installing.
- For better adhesion, scuff the bottom of the Make-A-Berm with sandpaper.
- Allow sealant and glue to cure for 24 hours before use. Colder temperatures may take longer.
- To remove the Make-A-Berm barrier, scrape with a flat-blade shovel.