



Patent US 6,626,322 B1



Instructions

Your new Smokers Cease-Fire® product is fully assembled and ready to use. However, we recommend additional weight be added to the bottom to avoid tip-over in adverse weather conditions.

To add additional weight:

1. Unscrew and remove black knob on the unit. Then tilt the neck to clear the opposite tab from slot and remove the top from the base.
2. Fill the liner pail with sand, approximately 1/3 to 1/2 full. Another option is to place some bricks or rocks inside the pail.
3. Once the weight has been added, place the top on the base. With the neck tilted, align the tab on the top with the slot on the base. Tilt the neck upright inserting the tab into the slot. Align the hole in front of the lid with the nut insert in the base and screw in the knob to secure top and bottom together.

To secure your unit in place:

You may use the holes on both sides of the bottom to either lock and/or chain the receptacle to prevent theft or damage.

Getting started

Once your Smokers Cease-Fire® is in place and is first used, you may experience a bit of smoke coming out of the top. This is normal, as it will take the disposal of a few cigarettes to use up the oxygen in the container.

When cleaning, make sure to clear any obstructions from the neck. Under heavy use conditions, it is recommended the unit be cleaned regularly to prevent excessive tar build up.

CAUTION

Smokers Cease-Fire® has been specially designed to limit the flow of oxygen, thereby eliminating the chance of fire. To function properly, this unit must be securely closed at all times.