

Justrite Folding Utility Tray

Instructions

To Open and Deploy the Tray

- 1 Unfasten the hook and loop restraining strap from around the tray.
- 2 Unfold the base material of the tray.
- 3 Unfold the sidewalls to form a right angle.
- 4 Grasp the inside corner of the remaining walls and gently pull outward until the tray pops open.
- 5 Adjust the corners as needed so all walls are upright and the tray is square.
- 6 Inspect the tray for any damage or contamination before use.



To Fold and Store the Tray

1. Remove any liquid or debris according to local safety and environmental regulations.
2. Clean the tray and allow it to dry completely.
3. Push one corner diagonally toward the opposite corner so the sidewalls fold inward.
4. Continue folding until the sidewalls are flat.
5. Fold the base material toward the folded sidewalls.
6. Wrap the hook and loop strap around the folded tray and fasten securely.

Maintenance and Storage

After use, clean the tray with lukewarm water and a water-based degreaser or other non-abrasive cleaner suitable for PVC materials. Rinse thoroughly and allow it to dry completely before storage. Keep the tray folded and secured with the strap to prevent damage when not in use.